

# Oxygen Forensic Suite 2

## Supported phone features matrix

Feature \ Phones	1 – Nokia and Vertu classic phones	2 - Sony Ericsson classic phones	3 – Nokia S60 platform smartphones	4 - UIQ2 platform smartphones	5 – UIQ3 platform smartphones	6 - Windows Mobile 5/6 devices	7 - Blackberry devices	8- Samsung phones	9- Motorola phones	10- Apple devices
<b>Cable connection</b>	Yes	Yes	Yes	-	Yes	-	Yes	Yes	Yes	Yes
<b>Bluetooth connection</b>	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes	-	NA
<b>Infrared connection</b>	Yes	-	Yes	Yes	-	-	NA	-	-	NA
<b>General phone information</b>	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
<b>Phonebook</b>	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
<b>Custom field labels for contacts</b>	NA	NA	Yes	Yes	Yes	NA	Yes	Yes	NA	NA
<b>Contact pictures</b>	Yes	-	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
<b>Speed dials</b>	Yes	-	Yes	Yes	Yes	-	-	-	-	Yes
<b>Caller groups</b>	Yes	-	Yes	Yes	Yes	Yes	-	-	Yes	NA
<b>Calendar</b>	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes
<b>Tasks</b>	Yes	-	Yes	Yes	Yes	-	-	-	NA	NA
<b>Notes</b>	-	-	-	-	-	-	-	-	-	Yes
<b>Incoming, outgoing and missed calls information</b>	Yes	Yes	Yes	-	-	Yes	Yes	Yes	Yes	Yes
<b>GPRS, EDGE, CSD, HSCSD and Wi-Fi traffic and sessions log</b>	NA	NA	Yes	Yes	-	-	-	NA	NA	NA
<b>Sent and received SMS,</b>	Sent SMS	NA	Yes	Yes	Yes**	-	-	NA	NA	NA

<b>MMS, E-mail messages log</b>										
<b>Deleted SMS messages information*</b>	-	-	Yes	-	Yes	-	-	-	-	-
<b>Flash SMS information*</b>	-	-	Yes	-	Yes	-	-	-	-	-
<b>SMS, MMS and E-mail messages in standard folders</b>	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes	Yes*****	Yes
<b>SMS, MMS and E-mail messages in custom folders</b>	Yes	NA	Yes	Yes	Yes	Yes***	-	-	NA	NA
<b>File system in phone memory and flash card</b>	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes/-	Yes	Yes/NA
<b>Photos, videos and voice records</b>	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes	Yes	Yes
<b>Geo event positioning</b>	NA	NA	Yes	NA	NA	NA	NA	NA	NA	NA
<b>Web Cache</b>	Yes****	-	Yes	-	-	Yes	-	-	-	Yes
<b>Web Bookmarks</b>	-	-	Yes*****	-	-	-	-	-	-	Yes
<b>Unicode support</b>	Yes	Yes	Yes	Yes	Yes	Yes	-	Yes	Yes	Yes
<b>Advanced search through phones database</b>	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes	Yes

- \* - Reading messages information available in Event Log section. Message must not be older than the number of days specified by "Log duration" parameter in system log application.

- \*\* - Only SMS information.
- \*\*\* - Only first-level custom folders.
- \*\*\*\* Only for Nokia Series 40 phones.
- \*\*\*\*\* Only for Nokia Series 60 2<sup>nd</sup> Edition and 3<sup>rd</sup> Edition Initial Release smartphones
- \*\*\*\*\* Only SMS

“Yes” means the feature is supported by the software.

“-” means feature is not supported by the software.

“NA” means feature not available for the device.

## 1 - Nokia and Vertu classic phones:

- Nokia: 1200, 2112, 2115, 2115i, 2127, 2270, 2275, 2280, 2285, 3210, 3310, 3315, 3320, 3321, 3330, 3350, 3360, 3361, 3390, 3395, 3410, 3510, 3570, 3580, 3585, 3590, 3610, 5110, 5130, 5190, 5210, 5510, 6110, 6150, 6190, 6210, 6250, 6310, 6310i, 6320, 6340, 6340i, 6360, 6370, 6385, 6510, 6590, 7110, 7160, 7190, 8210, 8250, 8310, 8390, 8810, 8850, 8855, 8890, 8910, 1680 Classic, 2125, 2320 Classic, 2323 Classic, 2330 Classic, 2600 Classic, 2605, 2608, 2610, 2626, 2630, 2650, 2660, 2680 Slide, 2700 Classic, 2760, 2855, 2865, 3100, 3105, 3108, 3109 Classic, 3110 Classic, 3120 Classic, 3125, 3128, 3152, 3155, 3155i, 3200, 3205, 3220, 3300, 3500 Classic, 3510i, 3520, 3555, 3560, 3586, 3586i, 3587, 3587i, 3588i, 3589i, 3595, 3600 slide, 3606, 3608, 3610 fold, 5000, 5070, 6070, 6080, 5100, 5130 XpressMusic, 5140, 5140i, 5200, 5220 XpressMusic, 5300, 5310 XpressMusic, 5610 XpressMusic, 6010, 6011, 6011i, 6012, 6015, 6020, 6021, 6030, 6060, 6061, 6062, 6066, 6085, 6086, 6088, 6100, 6101, 6102, 6102i, 6103, 6108, 6111, 6112, 6125, 6126, 6131, 6133, 6136, 6151, 6152, 6155, 6165, 6170, 6175i, 6178i, 6200, 6208 Classic, 6212 Classic, 6220, 6225, 6230, 6230i, 6233, 6234, 6235, 6245i, 6255, 6260 Slide, 6263, 6265, 6267, 6270, 6275, 6280, 6282, 6288, 6300, 6300i, 6301, 6303 Classic, 6500 Classic, 6500 Slide, 6555, 6560, 6585, 6600 Fold, 6600 Slide, 6610, 6650, 6651, 6700 Classic, 6800, 6810, 6820, 6820, 6822, 7070 Prism, 7088, 7100 Supernova, 7200, 7210 Supernova, 7210, 7250, 7250i, 7260, 7270, 7280, 7310 Supernova, 7360, 7370, 7373, 7380, 7390, 7500 Prism, 7510 Supernova, 7600, 7610 Supernova, 7900 Prism, 8208, 8600 Luna, 8800 Arte, 8800 Sirocco Edition, 8800, 8801, 8910i.
- Vertu: Ascent 2004, Ascent M 2006, Ascent Ti, Constellation, Signature 2002, Signature 2006, Signature 2008.
- Mobiado: Professional, Professional Executive.

**2 - Sony Ericsson classic phones:** 550im, 658c, 902c, C510, C702i, C902, C905, D750i, K758c, F500i, G502, J132, J300a, J300i, J300c, K300a, K300i, K300c, K310a, K310i, K310c, K320i, K320c, K330, K500c, K500i, K506c, K508c, K508i, K510i, K510c, K530i, K550i, K550c, K600i, K608i, K610i, K618i, V630i, K630i, K660i, K700c, K700i, K750i, K750c, K770i, K790a, K790i, K790c, K800i, K810i, K818c, K850a, K850i, K858c, S302, S500i, S700c, S700i, S710a, T226, T228, T230, T290c, T290i, T300, T302, T310i, T312, T610, T618, T630, T650i, T68, T68i, T68ie, T700, V600i, V640i, V800, V802SE, Z800i, W200i, W200c, W300i, W300c, W350, W380a, W380i, W550i, W550c, W580i, W580c, W595, W600a, W600c, W600i, W610i, W610c, W660i, W700i, W700c, W710i, W710c, W760i, W800i, W800c, W810i, W810c, W830i, W830c, W850i, W880i, W888c, W890i,

W900i, W908c, W910i, W980, Z1010, Z310a, Z310i, Z500a, Z520a, Z520i, Z520c, Z525a, Z530i, Z530c, Z550i, Z550c, Z555a, Z555i, Z558i, Z558c, Z600, Z608, Z610i, Z710i, Z710c, Z750i, Z770i, Z780i, C905.

### **3 - Nokia S60/S80/S90 platform smartphones:**

- Nokia: 3230, 3250, 3600, 3620, 3650, 3660, 5320 XpressMusic, 5500 Sport, 5630 XpressMusic, 5700 XpressMusic, 5730 XpressMusic, 5800 XpressMusic, 6110 Navigator, 6120 Classic, 6121 Classic, 6122 Classic, 6124 Classic, 6210 Navigator, 6220 Classic, 6260, 6290, 6600, 6620, 6630, 6631, 6638, 6650 (smartphone), 6670, 6680, 6681, 6682, 6710 Navigator, 6720 Classic, 7610, 7650, E50, E51, E52, E60, E61, E61i, E62, E63, E65, E66, E66, E70, E71, E71, E75, E90, N70, N71, N72, N73, N75, N76, N77, N78, N79, N80, N81, N82, N85, N86, N90, N91, N92, N93, N93i, N95 8GB, N95, N96, N97, N-Gage QD, N-Gage, 7700, 7710, 9300, 9300i, 9500.
- Samsung: GT-i7110, GT-I8150, INNOV8 (i8510), OMNIA HD, SGH-D700, SGH-D710, SGH-D720, SGH-D728, SGH-D730, SGH-G810, SGH-i400, SGH-i450, SGH-i520, SGH-i550, SGH-i560, SGH-i570, SGH-L870, SGH-Z600.
- Panasonic: X700, X800.
- Siemens: SX1.
- LG: KT-615

### **4 - UIQ2 platform smartphones:**

- Sony Ericsson: P800, P802, P900, P908, P910i, P910c, P910a.
- Motorola: A1000, A1010, A920, A925.
- Benq: P30, P31.
- Nokia: 6708.

### **5 - UIQ3 platform smartphones:**

- Sony Ericsson: G700, G700c, G700i Business Edition, G702, G900, M600i, M608c, P1c, P1i, P990i, W950i, W958c, W960i.
- Motorola: MotoRizr Z8, MotoRizr Z10.

### **6 - Windows Mobile 5/6 devices:**

- Acer: c510, c530, c531, n300, N310, n311, n320, n321
- Airis: T610, T620
- Amoi: E75, E76, E78, E850, E860
- AnexTEK: moboDA 3160, moboDA 3360, moboDA 3380, SP310
- AnyDATA: ASP-210C

- Asus: Lamborghini ZX1, M530w, M536, M930, Mars II, MyPal A626, MyPal A632, MyPal A636, MyPal A636N, MyPal A639, MyPal A686, MyPal A696, P305, P320, P525, P526, P527, P535, P550, P552w, P560, P735, P750
- AT Mobile: AT Bear, AT Cobra, AT Eagle, AT Falcon, AT Pelican
- ATT: 8525, BlackJack II, Moto Q Global, Palm Treo, Pantech Duo, Tilt
- BenQ: E72, P51
- Cingular: 2125, 3125, 8125
- Dell: X51, X51v
- Dopod: 310, 577W, 586W, 595, 818 Pro, 838 Pro, 838, 900, C500, C720W, C730, D600, D802, D810, M700, P100, P800W, S300, U1000
- Eten: G500, G500+, Glofiish M750, Glofiish M800, Glofiish M810, Glofiish V900, Glofiish X500, Glofiish X500+, Glofiish X600, Glofiish X610, Glofiish X650, Glofiish X800, Glofiish X900, M550, M600, M600+
- Everex: NEON
- Fifth Media: A308
- Fly: IQ-110
- Fujitsu Siemens: Pocket LOOX C550, Pocket LOOX N100, Pocket LOOX N110, Pocket LOOX N500, Pocket LOOX N520, Pocket LOOX N560, Pocket LOOX T810, Pocket LOOX T830
- Gigabyte: g-Smart i, g-Smart i+, g-Smart i120, g-Smart i128, g-Smart i300, g-Smart i350, g-Smart MS800, g-Smart MS804, g-Smart MS808, g-Smart MS820, g-Smart MW700, g-Smart MW998, g-Smart Q60, g-Smart t600, g-Smart
- Hewlett-Packard: iPaq 111 Classic, iPAQ 114 Classic, iPaq 211 Enterprise, iPAQ 214 Enterprise, iPAQ 500, iPAQ 510, iPAQ 512, iPAQ 514, iPAQ 614 Business, iPAQ 614c, iPaq 910, iPAQ 914c, iPAQ hw6910, iPAQ hw6915, iPAQ hw6920, iPAQ hw6925, iPAQ hw6940, iPAQ hw6945, iPAQ hw6965, iPAQ hx2190, iPAQ hx2195, iPAQ hx2490, iPAQ hx2495, iPAQ hx2790, iPAQ hx2795, iPAQ rw6815, iPAQ rw6818, iPAQ rw6828, iPAQ rx1950, iPAQ rx1955
- HTC: Advantage X7500, Advantage X7510, Advantage, Apache, Artemis, Athena, Atlas, Breeze, Cavalier, Elf, Erato, Excalibur, Faraday, Galaxy, Gene, Herald, Hermes, Kaiser, Libra, Love, Mogul, Monet, Mteor, Muse, Nike, Omni, Oxygen, P3300, P3400, P3470, Panda, Pharos, Prophet, S630, S710, Sedna, Sirius, Star Trek, Titan, Tornado, Touch Cruise P3650, Touch Cruise, Touch Diamond, Touch Dual, Touch P3452, Touch Pro, Touch Viva 2223, Touch, Trinity, TyTN, Tytn-II, Universal, Volans, Vox, Wings, Wizard
- i-mate: Jama 101, Jama 201, Jama, Jamin, JAQ, JAQ3, JAQ4, JasJam, JasJar, K-Jam, PDA-L, PDA-N, SmartFlip, SP5, SP5m, SPjas, SPL, Ultimate 5150, Ultimate 6150, Ultimate 7150, Ultimate 8150, Ultimate 8502, Ultimate 9150, Ultimate 9502
- i-teq: Bond, Laser, X-Bond
- IzenMobile: KRMA, KSMT
- Kinpo: Everex NEON, iDO S601, iDO S630, SP70, SP70R, SP90
- Lenovo: ET960, ET980, i921
- LG: Incite, KC1, KS20
- Mio: A502, A702, Mio P550, Mio P560, P360
- Mitac: A201, A501, A701
- Motorola: Franklin, MC35, MC9000, MC9090-G, MC909X-K, MC909X-S, MOTO Q q9, MOTO Q9m, Norman, Q GSM, Q, Q8, Q9, Q9h
- MWG: Atom V, Zinc II

- Neonode: N2
- O2: XDA Argon, XDA Atom Exec, XDA Atom Life, XDA Atom Pure, XDA Atom, XDA Cosmo, XDA Exec, XDA Flame, XDA Graphite, XDA IQ, XDA mini S, XDA Neo, XDA Nova, XDA Orbit, XDA Orion, XDA Stealth, XDA Terra, XDA Trion, XDA Zinc
- Okwap: K728, K868, K869, K871, S868
- Orange: SPV C100, SPV C200, SPV C600, SPV C700, SPV E600, SPV E610, SPV E650, SPV F600, SPV M3000, SPV M3100, SPV M5000, SPV M600, SPV M650, SPV M700
- ORSiO: G735, N725 GPS, N725, P745
- Palm: Treo 500, Treo 750, Treo 750v, Treo Pro
- Pantech: Matrix Pro
- Paragon Wireless: Hipi-2200, Hipi-2300
- Pharos: 600 GPS Phone, Traveller GPS 525
- Pocket Navigator: PN-3550, PN-3560, PN-P201, PN-P550 A, PN-P550
- Psion Teklogix: Ikon, WORKABOUT PRO G2, WORKABOUT PRO
- Qool Labs: QDA Icon, QDA Lite, Twins 178
- Qtek: 8300, 8310, 8500, 8600, 9000, 9100, 9600, G100, G200, S200, S310
- Quanta: Apollo, Atom Exec, Atom Pure, Atom
- Quest: Pocket PC6700
- RoverPC: C6, E5, G5, G6, M5, N6, N7, P6, P7, Q5, Q6, R5, S5, S6, S7, W5
- Samsung: Epix, Omnia, Propel Pro, Saga, SGH-i200, SGH-i310, SGH-i320, SGH-i600, SGH-i710, SGH-i718, SGH-I718+, SGH-I720, SGH-I728, SGH-i740, SGH-I750, SGH-i760, SGH-i780, SGH-i900 (WITU)
- Socket Mobile: SoMo 650 DX, SoMo 650
- Sony Ericsson: XPERIA X1
- TDS: Nomad 800B, Nomad 800L, Nomad 800LC, Nomad 800LE, Ranger 300X, Ranger 500X
- T-Mobile: Dash, MDA compact IV, MDA Pro, MDA Vario, Shadow, Wing, Wings US
- Toshiba: Portege G500, Portege G710, Portege G810, Portege G900, Portege G910
- Velocity Mobile: 103, 111
- Vodafone: 1210, V1240, VPA IV
- Voxtel: W210, W420, W520, W740

**7 - Blackberry devices:** 8100, 8110, 8120, 8130, 8300, 8310, 8320, 8330, 8350i, 8800, 8820, 8830, 8900, 9500, 9530, Bold, Flip 8220.

**8 - Samsung phones:** SGH-A226, SGH-A227, SGH-A237, SGH-D500, SGH-D500E, SGH-D508, SGH-D510, SGH-D600, SGH-D600E, SGH-D608, SGH-D610, SGH-D618, SGH-D780-Duos, SGH-D788-Duos, SGH-D820, SGH-D820E, SGH-D828, SGH-D828E, SGH-D880-Duos, SGH-D888+, SGH-D888-Duos, SGH-D900, SGH-D900i, SGH-D908, SGH-D908i, SGH-D980-Duos, SGH-D988-Duos, SGH-E200, SGH-E200B, SGH-E208, SGH-E208B, SGH-E236, SGH-E250, SGH-E250D, SGH-E250W, SGH-E251, SGH-E251C, SGH-E256, SGH-E258, SGH-E258D, SGH-E340, SGH-E348, SGH-E350, SGH-E358, SGH-E360, SGH-E368, SGH-E370, SGH-E370L, SGH-E378, SGH-E380, SGH-E388, SGH-E390, SGH-E398, SGH-E480, SGH-E488, SGH-

E500, SGH-E508, SGH-E590, SGH-E598, SGH-E640, SGH-E648, SGH-E690, SGH-E698, SGH-E730, SGH-E738, SGH-E740, SGH-E747, SGH-E748, SGH-E750, SGH-E758, SGH-E760, SGH-E768, SGH-E780, SGH-E788, SGH-E830, SGH-E838, SGH-E840i, SGH-E848i, SGH-E890, SGH-E898, SGH-F110, SGH-F118, SGH-F150, SGH-F158, SGH-F250, SGH-F250L, SGH-F258, SGH-F260, SGH-F265, SGH-F268, SGH-F270, SGH-F270L, SGH-F278, SGH-F480L, SGH-F488E, SGH-G600, SGH-G608, SGH-G618, SGH-G808E, SGH-I858, SGH-J150, SGH-J158, SGH-J210, SGH-J218, SGH-J700, SGH-J700L, SGH-J706, SGH-J708, SGH-J708C, SGH-J808E, SGH-L250, SGH-L258, SGH-L310, SGH-L318, SGH-L600, SGH-L608, SGH-L750, SGH-M150, SGH-M158, SGH-M3510, SGH-M610, SGH-M618, SGH-P180, SGH-P200, SGH-P220, SGH-P240, SGH-P260, SGH-P780, SGH-P788, SGH-P850, SGH-P858, SGH-T219, SGH-T229, SGH-T301, SGH-T309, SGH-T329, SGH-T336, SGH-T339, SGH-T409, SGH-T429, SGH-T439, SGH-T459, SGH-T509, SGH-T619, SGH-T729, SGH-T739, SGH-T809, SGH-U708E, SGH-U808E, SGH-U900L, SGH-U908E, SGH-X437, SGH-X576, SGH-X670, SGH-X678, SGH-X690, SGH-X698, SGH-X700, SGH-X708, SGH-A137, SGH-A26A, SGH-A437, SGH-B110, SGH-B110L, SGH-B130, SGH-B130S, SGH-B138, SGH-B210, SGH-BC01, SGH-C160, SGH-C160B, SGH-C160G, SGH-C161, SGH-C165, SGH-C168, SGH-C168B, SGH-C180, SGH-C280, SGH-C288, SGH-C327, SGH-C420, SGH-C425, SGH-C426, SGH-C450, SGH-C458, SGH-CC03, SGH-D488, SGH-E100, SGH-E108, SGH-E1110, SGH-E330, SGH-E330C, SGH-E330N, SGH-E335, SGH-E338, SGH-E420, SGH-E428, SGH-E630, SGH-E630C, SGH-E638, SGH-E700, SGH-E700A, SGH-E708, SGH-E746, SGH-E800, SGH-E800C, SGH-E808, SGH-E820, SGH-M110, SGH-M120, SGH-M130L, SGH-M140, SGH-S500, SGH-S508, SGH-T101, SGH-T101G, SGH-T109, SGH-T209, SGH-T319, SGH-T329, SGH-X100, SGH-X108, SGH-X460, SGH-X490, SGH-X495, SGH-X497, SGH-X540, SGH-X550, SGH-X560, SGH-X560L, SGH-X566, SGH-X600, SGH-X600A, SGH-X608, SGH-X620, SGH-X628, SGH-X640, SGH-X648, SGH-X650, SGH-X658.

**9 – Motorola phones:** T720, T725 A810, MOTO W388, MOTO ZN200, MOTOROKR EM28 (EM330), MOTOROKR EM30, MOTOZINE ZN5, ROKR EM25 (MOTO EM325), VE538 A845, C380, C650, C980, E1000, E1070, E380, E398, E550, E770, L2, L6, MOTO Z9 (Z9N), MOTOACTV W6, MOTOKRZR K1, MOTOKRZR K1m, MOTOKRZR K3, MOTOPEBL U3, MOTOPEBL U6, MOTORAZR maxx V6, MOTORAZR V3 (CLDC 1.0), MOTORAZR V3 (CLDC 1.1), MOTORAZR V3e, MOTORAZR V3i, MOTORAZR V3m, MOTORAZR V3re, MOTORAZR V3t, MOTORAZR V3xx, MOTORAZR2 V8, MOTORAZR2 V9, MOTORAZR2 V9x, MOTORIZR Z3, MOTOROKR E1, MOTOROKR E8, MOTOSLVR L7, MOTOSLVR L72, MOTOSLVR L7i, L7e, MOTOSLVR L9, V1050, V1100, V180, V195, V197, V220, V300, V360, V400, V500, V550, V551, V600, V620, V635, V80, V975, V980, W230, W270, W490.

**10 – Apple devices:** iPhone, iPhone 3G, iPod Touch.